

Activating your City School District of New Rochelle MiFi router

Activación del Enrutador del City School District of New Rochelle



Box Contents / Contenido de la Caja



1. Box / Caja

2. SIM Card (installed) / Tarjeta SIM (instalada)

3. MiFi Router / MiFi Enrutador


4. Power Adapter / Adaptador de Corriente

5. Instructions / Instrucciones

Step 1: Charge / Paso 1: Cargar




Step 2: Turn On / Paso 2: Encender



Step 3: Connect / Paso 3: Conectar

NETWORK / RED: CSDNR_MiFi



IMPORTANT / IMPORTANTE

You must connect your Chromebook to ANY NETWORK before connecting to MiFi in order to automatically download the MiFi PASSWORD

Debes conectar su Chromebook a CAULQUIER RED antes de conectarse a MiFi para descargar automáticamente la CONTRASEÑA MiFi